LED Bluetooth Symphony Controller

Technical Parameters

Product name	Bluetooth Symphony Controller
Support system	Android 4.4 and above / iOS 11.0 and above
Connection mode	Bluetooth 4.0
Remote control	24key

Product Description

Controller and remote control functions:



Long press (5 seconds): Off
Short press: open
Mode switch



The plastic sheet has the function of isolating the battery. When using the remote control, pull out the plastic sheet

Download App Software

Please search LED LAMP in major Appcenters, or scan below QR code.

1. Download the "LED LAMP" APP with your mobile phones by scanning the QR code on user manual or search the "LED LAMP" APP in iPhone APP store or Google play store.
2. After the APP are downloaded successfully, you need to turn on Bluetooth function on your phone firstly, then plug in the strip light, then open the APP, your APP will pair with the strip light automatically and you can control it.

Unable to Connect Troubleshooting

(1) Check if the power supply of the light strip is normal.
(2) Check if the Bluetooth is turn on.
(3) Check if there are other mobile phone are connected, Bluetooth 4.0 only support connections one to many, dose not support many to many.
(4) Check APP Bluetooth setting if the phone is connected to the device, if connect, exit the APP and reopen, the APP will go to connect automatically.
(5) Normal operations and can not connect, please exit the APP and reopen.
(6) Exit APP, restart mobile phone, power on the strip light, reopen the APP, then them will connect automatically.

☆ First, you need to turn on the Bluetooth function of your phone.
☆ For Android phone users, you should also turn on the location function and allow permissions.

Instructions

On the home page, manually pull down and refresh, and APP automatically searches for nearby devices. Click "LED DMX 03-XXXX" device to enter the lighting control interface.



1. Setting: RGB sorting and pixels.



Set the pixels

2. Color: select color, customize storage color, and adjust brightness



3. Mode: select mode, adjust speed, brightness.

4. Music: voice control and music, voice control has four modes, music needs mobile phone to play songs to carry out.

Voice control mode

Mode switch

The song list
Add the songs

5. Timing: set the timing on/off, time, week.